


Heat Pump Balance Point Chart

1-1/2 thru 3-1/2 Ton (Split and Package)

Based on 70° Return Air 400 CFM/TON



Heat Pump Balance Point Chart

4 thru 10 Ton (Split and Package)
Based on 70° Return Air 400 CFM/TON

